



INSTALLATION INSTRUCTIONS for HS-30 12" WIDE WALL MOUNT HAND SINK with SIDE SPLASHES

INCLUDES:

- (A) 12" HAND SINK with SIDE SPLASHES
- (B) BACKSPASH WALL MOUNT FAUCET
- (C) WALL MOUNT BRACKET

1. Install FAUCET (B) on 12" HAND SINK with SIDE SPLASHES (A) and hook up water inlet leads (not provided)
2. Hang 12" HAND SINK with SIDE SPLASHES (A) on WALL BRACKET (C).
3. Install Drain with plumbers putty on top and the rubber washer & locknut below. Make sure top of drain is below surface to allow proper drainage.
4. Hook up water and drain lines to complete the installation.

