
# **Stationary Wall Brackets**

## **ASSEMBLY INSTRUCTIONS**

## **CAUTION**

INSPECT CONTENTS IMMEDIATELY AND FILE CLAIM WITH DELIVERING CARRIER FOR ANY DAMAGE. SAVE YOUR BOX AND ALL PACKING MATERIALS.

YOU ARE RESPONSIBLE FOR DAMAGE TO YOUR UNIT IF RETURNED IMPROPERLY PACKED.



## Parts List

qtydescription1.....mounting plate1.....bracket

### Mounting Plate

Place the mounting plate through the vertical section of the wall bracket as shown in the picture.

#### Positioning

Hold the bracket to the wall in the desired mounting location and ensure proper spacing is allowed for the shelf length. Mark the location of the holes in the mounting plate.

**Note:** Depending on construction of wall, brackets should be attached to studs, in-wall-grounds, or solid part of brick or concrete wall with appropriate fasteners. Six fasteners must be used per bracket for proper stability. **Hint:** Place the shelf over the bracket before marking mounting plate locations. This will help with proper location of bracket, and aid in the overall mounting process. Check the shelf with a level prior to mounting. If the wall is not plumb, spacer washers should be added. (mounting screws and spacers are not included)

#### Secure

3)

Mount brackets securely to the wall. Place shelf over brackets.



Note: Wall mounted units must be attached to a properly constructed and sound wall. For walls constructed of wood or steel studs, the mounting points must be directly on the stud or suitable in-wall-grounds of plywood or sheet metal. Eagle Group cannot be held responsible for the failure of the device or any other devices due to improper installation.



EG9874 Revised 01/08



- 100 Industrial Boulevard, Clayton, Delaware 19938-8903 U.S.A. www.eaglegrp.com
- Phone: 302/653-3000 (Foodservice) 800/441-8440 (MHC/Retail) 800/637-5100
- Fax: 302/653-2065

Eagle Foodservice Equipment, Eagle MHC, SpecFAB, and Retail Display are divisions of Eagle Group. ©2008 by the Eagle Group