



Coupe Plate
6940E630 D 12"
6940E6033 D 11"
(Plate Cover 5379S792)
(Plate Cover 5379S804)
6940E654 D 10 5/8"
(Plate Cover 5379S802)



Oval Plate
6940E6072 L 11" W 10"
6940E6060 L 8 7/8" W 7 7/8"
6940E6059 L 6 3/4" W 5 7/8"



Coupe Platter
6940E641 L 13 3/4" W 8 1/2"
6940E640 L 12" W 7 1/4"
Coupe Plate
6940E653 L 9" W 6 3/8"
6940E652 L 8" W 5 1/2"



Coupe Plate Large
6940E649 L 14" W 6"
6940E648 L 12" W 4 1/2"



Round Coupe Bowl
6940E671 D 11" H 2 1/2" (64 1/4 oz)
(Plate Cover 5379S804)
Round Coupe Dish
6940E605 D 9 1/2" H 2" (38 3/4 oz)
6940E634 D 8" H 1 7/8" (24 1/2 oz)
6940E650 D 6 3/8" H 1 3/8" (10 oz)



Flared Serving Bowl
6940E639
D 11" H 2 7/16" (53 oz)
6940E670
D 9 1/2" H 2 1/2" (39 oz)



Flared Bowl
6940E651 D 7 5/8" H 2 5/8" (33 oz)
6940E636 D 6" H 2 1/4" (16 oz)
6940E637 D 4 1/2" H 1 5/8" (6 1/2 oz)
6940E638 D 3" H 1 1/8" (2 1/2 oz)



Oval Bowl
6940E685 L 10" W 6 1/4" H 2 3/4" (30 oz)
6940E684 L 8" W 5" H 2 1/4" (15 1/2 oz)
6940E6023 L 6" W 3 3/4" H 1 3/4" (7 oz)
6940E6022 L 4" W 2 1/2" H 1 1/8" (1 3/4 oz)



Deep Bowl
6940E612
D 8 1/4" H 2 3/8" (37 oz)
Cereal Bowl
6940E6024
D 6 3/4" H 2" (16 oz)



Rice Bowl
6940E694 D 7 3/4" H 3 3/4" (48 oz)
6940E693 D 6 1/4" H 3" (28 oz)
6940E692 D 4 1/2" H 2 1/4" (9 oz)
Lid w/Slot
6940E695 D 8" (Fits E694)
6940E698 D 6 5/8" (Fits E693)
6940E697 D 4 5/8" (Fits E692)
Saucer Double Well
6940E6016 D 6 1/2" (Fits E692)



Bowl
6940E6025
D 5 1/2" H 2 1/8" (12 oz)
6940E6044
D 4 3/4" H 2 3/8" (10 1/2 oz)



Can Cup
6940E642 L 4 3/4" H 2 1/2" (9 1/2 oz)
6940E643 L 3 1/2" H 2" (4 1/2 oz)
Saucer
6940E644 D 6 3/8" (Fits E642)
6940E645 D 5" (Fits E643)



Low Cup
6940E614 L 5 1/4" H 2 3/4" (12 oz)
6940E615 L 4 3/4" H 2 3/8" (8 oz)
6940E688 L 3 3/8" W 2 1/2" H 1 5/8" (3 oz)
Saucer Double Well
6940E6016 D 6 1/2" (Fits E615, E614)
6940E687 D 4 5/8" (Fits E688)



Coupe Mug
6940E6056
L 5 1/4" H 4 1/8"
(15 1/2 oz)



Unhandled Cup
6940E691
L 2 1/2" H 2"
(3 oz)



Unhandled Can Creamer
6940E6045
L 2 1/4" H 2 5/8"
(3 1/2 oz)



Sauce Dish
6940E618
D 4" H 1 1/4"
(4 1/4 oz)



Sauce Dish
6940E617
D 3 1/2" H 1"
(1 oz)



Curved Chinese Spoon
6940E6011 L 6 1/2"
Spoon Rest
6940E6013 L 4" H 2"



Chinese Spoon
6940E621 L 5" H 1 3/4"
Chinese Spoon Rest
6940E620 L 3 1/2" H 2 1/8"