



Taster Bowl
11070576 D 5"
(10 1/4 oz)



Taster Dip
11070575
D 2 1/2"
(1 3/4 oz)




Sauce Pot
11070608
D 2 1/2" H 3"
(6 oz)



Pourer
11070557
W 3" H 2 7/8"
(3 oz)



Quench Mug
11010590 L 5" H 5 1/8" (16 oz)
11010591 L 4 1/2" H 4 3/4" (12 oz)
11010592 L 4 1/4" H 4 3/8" (10 oz)
11010593 L 4 1/8" H 4 1/8" (8 oz)
11010594 L 3 1/8" H 2 7/8" (3 oz)



Wooden Charger Plate
6515T345 Light L W 11 7/8" (Inner Wells L 7 1/2" W 2")
6515T346 Dark L W 11 7/8" (Inner Wells L 7 1/2" W 2")
Creations Glass Charger Plate
6506G231 L W 12" (Inner Wells L 7 1/2" W 2")



Stack Bowl
1340X0008 D 5 1/2" (25 oz)
Saucer Double Well
1340X0040 D 6 1/2"



Stack Bowl
1340X0009 D 4 1/2" (15 oz)
Saucer Double Well
1340X0040 D 6 1/2"



Stack Bowl
1340X0010 D 3 1/2" (8 oz)
Saucer
1340X0043 D 5"



Stack Mug
1340X0013 L 5 1/8" H 5" (16 oz)
1340X0014 L 4 1/2" H 4 5/8" (12 oz)
1340X0015 L 4 1/4" H 4 3/8" (10 oz)
1340X0016 L 4 1/4" H 4" (8 oz)
1340X0017 L 3" H 2 7/8" (3 oz)

Saucer
1340X0040 Double Well D 6 1/2" (Fits 0013)
1340X0041 Single Well D 6 1/2"
(Fits 0014, 015)
1340X0042 D 6" (Fits 0016)
1340X0043 D 5" (Fits 0017)



Cup
1340X0018 L 5 3/4" W 3 5/8" (16 oz)
1340X0019 L 5 1/4" W 3 1/4" (12 oz)
1340X0020 L 5" W 3 1/8" (10 oz)
1340X0021 L 4 5/8" W 2 7/8" (8 oz)
1340X0022 L 4 3/8" W 2 1/2" (6 oz)
1340X0023 L 3 1/2" W 2 1/8" (3 oz)

Saucer
1340X0042 D 6"
(Fits 0018, 0019, 0020, 0021, 0022)
1340X0043 D 5"
(Fits 0023)



Beverage Pot W/Lid
1340X0025 L 6 1/8" W 5" H 5 5/8" (21 oz)
1340X0027 L 5 7/8" W 4 5/8" H 4 3/4" (12 oz)
1340X0026 Lid No 1



Jug
1340X0029 L 4 1/2" H 3 1/2" (10 oz)
1340X0030 L 3 5/8" H 2 5/8" (5 oz)
1340X0031 Unhandled
L 2 1/2" H 2 3/8" (3 oz)



Covered Sugar W/Lid
1340X0032 (7 oz)
1340X0033 Lid